












Speed / Torque Curves

200V



100V



A : CONTINUOUS DUTY ZONE

B : INTERMITTENT DUTY ZONE

* When combined with SGDH-04 FE amp.