

FEATURES

- Compatible with controllers that output +/-10V analog torque commands for U & V phases
- Reduced offset drift
- **FAULT PROTECTIONS**
 Short-circuits
 output to output
 output to HV (+)
 output to HV (-)
 Over / under voltage
 Over temperature
 Self-reset or latch-off
- **No Transformer Required!**
 Operates from power supplies that rectify the line directly with full optical isolation between signal and power stages.
- **CURRENT LIMITING**
 User selectable, I²T Limit with, indicator signal for control system
- **Greater than 3 kHz Bandwidth**

WORKS WITH POPULAR CONTROLLERS

- **Technology 80** 5651A
- **PMD** MC1231A Chipset
- **Delta Tau** PMAC
- **MEI** DPS Series
- **Galil** DMC-1700

THE OEM ADVANTAGE

- Internal solderless header configures amplifier for plug and play operation

MODEL	POWER	I-CONT (A)	I-PEAK (A)
7225X1	24~180VDC	10	25



FEATURES

The 7xx5X1 model is a PWM servo-amplifier for AC Brushless servomotors that are commutated externally by digital control systems that output two +/-10V signals that represent the current command to the motor U and V windings. The amplifier synthesizes the current command for the W winding.

Control cards take feedback from an encoder on the motor and use various techniques to determine the rotor position. When this has been done, the controller is able to output two signals that correspond to the current in the U and V windings to produce torque in the motor. The amplifier synthesizes the W winding current from UV signals that are 120 electrical degrees apart.

Amplifier adjustments with this system consist of inductance compensation, current limit, transconductance, and offset. Thereafter, the controller does all of the velocity and/or position control of the motor.

Internal solderless sockets let the user configure the various gain and current limit settings to customize the amplifiers for a wide range of loads and applications. Header components permit compensation over a wide range of load inductance's to maximize bandwidth with different motors.

The /Enable input active logic-level is jumper-selectable to ground or +5V to interface with all types of control cards.

MOSFET output stage deliver four quadrant power for bi-directional acceleration and deceleration of motors.

All models are protected against output short circuits (output to output, output to ground, output to +HV) and heatplate overtemperature. With the /Reset input open the amplifier will latch off until powered-down or the /Reset input is toggled. The amplifier will reset itself automatically from faults if the /Reset input is wired to GND.



MODEL 7225X1

LINE-ISOLATED AC BRUSHLESS SERVO AMPLIFIER WITH +/-10V ANALOG U-V INPUTS

TECHNICAL SPECIFICATIONS

Test conditions: 25°C. ambient, Load = 400uH in series with 1Ω, +HV = 180V

MODEL		7225X1
OUTPUT POWER		
Peak power		25 A @ 170 VDC
Peak time		2.4 sec at peak power independent of polarity reversal
Continuous power		10 A @ 180 VDC
OUTPUT VOLTAGE		
On-resistance (Ro, ohms)		0.2
Max PWM Peak Output Voltage		$\pm V_{out} = (VDC) \times (0.97) - (Ro) \times (Io)$
INPUT POWER		
DC voltage		22~186 VDC
Input current @ continuous output rating		10 A
LOAD INDUCTANCE		
Minimum inductance		400 μH.
Maximum inductance		No maximum. Bandwidth varies with inductance, +HV, and header parts.
BANDWIDTH		
Small signal		-3dB @ 3 kHz with minimum load at nominal supply voltage. Varies with load inductance and header values
PWM OUTPUTS		
PWM frequency		25 kHz
Modulation		Carrier-cancellation, 50% duty cycle at 0 V output
REFERENCE INPUT		
		Differential, 94 kΩ max. to 47 kΩ min. between inputs, ±20 V maximum
POTENTIOMETERS		
R14 U Ref Fine Gain	Default = Center	CW increases gain of U output phase current.
R26 V Ref Fine Gain	Default = Center	CW increases gain of V output phase current.
R49 U phase current Zero		Adjusts U output current to zero with U and V inputs = 0 V.
R41 V phase current Zero		Adjusts V output current to zero with U and V inputs = 0 V.
INTERNAL JUMPER		
JP1 /Enable input active polarity	Pos. 1-2 (default) Pos. 2-3	Gnd enables amplifier, open or +5 V inhibits. Gnd inhibits, open or +5 V enables
LOGIC INPUTS		
/Enable	Default = GND active	GND enables channel open or >2.5V inhibits with JP1 on 1-2. If JP1 on 2-3 then GND inhibits Response time is 1 ms from enable active to amplifier output ON.
/Motemp	Motor temp sensor.	HI (open) = Motor HOT, amp channel shuts down. Non-latching. LO (gnd) = Motor OK, amp channel will operate.
/Reset	Default = Open Input resistance Logic threshold voltage Input voltage range	GND resets latching fault condition, ground for self-reset every 1 s. 10kΩ to +5V, R-C filters on inputs 2.5V (Schmitt trigger inputs with hysteresis, 74HC14) 0V to +32VDC
LOGIC OUTPUTS		
/Normal		LO (current sinking) when channel is Enabled AND OK Amp OK = (NOT Short) AND (NOT Over, Undervoltage, or Basetemp) AND (MotorTemp OK) +5V (no load). Output is N-channel MOSFET drain terminal with 10kΩ pull-up resistor to +5V On resistance Ro = 5Ω. Max sink current of 250 mA. max off-voltage = 50VDC
/CurrLimit	HI output voltage LO output voltage	HI when amplifier is not current limiting; LO when current is limit is active. +5V (No load). Output is LM339 open collector with 10kΩ pullup resistor to +5V Max sink current of 15 mA, max off voltage = 32VDC
AmpOK	HI output voltage LO output voltage	Opto-isolated signal: opto-transistor output stage of optocoupler Transistor is ON when Amp is OK (see above) One output is connected to pins 7 & 19 of both J1 & J3
STATUS LEDS		
Amp OK	Blinking Green	Power OK, no faults, amp will run when enabled
Normal	Solid Green	Amplifier OK AND Amp Enabled
Fault	Solid Red	Amplifier NOT OK (Over voltage, /Motemp not connected or open)
Latching Fault	Blinking Red	Heatplate overtemp or short circuit (output-output, output-ground, output-+HV or internal)
MONITOR OUTPUTS		
Current Monitor U		Motor winding current in U phase: ±10 V @ ±25 A or 2.5 A/V (2.2 kΩ, 4.7 nF R-C filter)
Current Monitor V		Motor winding current in V phase: ±10 V @ ±25 A or 2.5 A/V (2.2 kΩ, 4.7 nF R-C filter)



MODEL 7225X1

LINE-ISOLATED AC BRUSHLESS SERVO AMPLIFIER

WITH +/-10V ANALOG U-V INPUTS

PROTECTIVE FEATURES

Short circuit	Latches unit OFF (Power off/on, or ground at /Reset input resets)
Overtemperature	Latches unit OFF at 70°C on heatplate (Power off/on, or ground at /Reset input resets) <i>Wire /Reset input to ground for automatic reset after latching fault</i>
Under voltage	Shutdown at DC buss < 22 VDC
Over voltage	Shutdown at DC buss > 195 VDC
Current-limiting	(Amplifier operation resumes when internal DC buss is NOT Under voltage or NOT Over voltage) Continuous current and I ² T limit set by header components Current is reduced to continuous setting when I ² T limit is reached. I _u , I _v are hardware limited to 26A, whereas I _w = -(I _u + I _v) at all times Maximum I ² T setting (H13 = H14 = 0 ohms) will activate latching fault after 25Arms for 2.5s Minimum I ² T setting (H13 = H14 = Open) will activate latching fault after 25Arms for 80mS Limiting action reduces transconductance so relative amplitude of U,V,W currents is maintained for no loss of phase /CurrLimit output indicates when current limiting is active. Amplifier will shutdown (latching fault) if I _w > 29A at any time.

AMPLIFIER DISSIPATION

Watts maximum at Vref = 0, amplifier enabled	7 W
Watts @ continuous current	60 W

THERMAL REQUIREMENTS

Storage temperature range	-30°C to +85°C
Operating temperature range	0° to 70°C baseplate temperature
Thermal resistance (heatplate to ambient):	No heatsink or fan: 2.7 deg. C/W; With heatsink, no fan: 1.6 deg. C/W No heatsink with fan: 1 deg. C/W; With heatsink and fan: 0.4 deg. C/W


MECHANICAL

Size	7.35 x 4.4 x 1.40 in. without optional heatsink
Weight	1.48 lb. (0.67 kg)

CONNECTORS

J1	Power & Motor connections	6-position Euro connector
J2	Signal connections	25-position female Sub-D type. #4-40 standoffs for cable shell lock screws

FUNCTIONAL DIAGRAM



CONNECTORS

J1 POWER AND MOTOR WINDING CONNECTIONS

Connector type: Euro style terminal block.

PIN	SIGNAL	FUNCTION
1	Motor W	Amplifier output to "W" winding of motor
2	Motor V	Amplifier output to "V" winding of motor
3	Motor U	Amplifier output to "U" winding of motor
4	Chassis Gnd	Chassis safety ground. Also for cable shield of motor cable.
5	HV(-)	DC Power Gnd/Return (<i>Note: HV is isolated from 0V signal ground</i>)
6	HV(+)	DC Power Input


J2 SIGNAL CONNECTIONS

Connector type: Female Sub-D, 25-position, #4-40 locking standoffs


PIN	SIGNAL	FUNCTION	PIN	SIGNAL	FUNCTION
1	Safety GND (Case)	Chassis ground. Use to ground cable shield. Not connected to internal signal ground (J3-12, 13,16).			
2	U Ref (+)	Positive terminal of differential +/-10V analog command input	14	U Ref (-)	Negative terminal of differential +/-10V analog command input
3	V Ref (+)	Positive terminal of differential +/-10V analog command input	15	V Ref (-)	Negative terminal of differential +/-10V analog command input
4	N.C.		16	0V.	Signal ground.
5	/Enable input	Amplifier enable	17	N.C.	
6	/Normal output	Mosfet output amp status	18	N.C.	
7	Amp OK (-) output	Opto-isolator emitter (NPN)	19	Amp OK (+) output	Opto-isolator collector (NPN)
8	N.C.		20	N.C.	
9	/CLIMIT	Current limit status	21	Motemp	(Note 1)
10	Current Monitor U	+/-10V @ +/-25 A	22	/Reset input	
11	Current Monitor V	+/-10V @ +/-25 A	23	N.C.	(Note 2)
12	0V.	Signal ground.	24	N.C.	(Note 2)
13	0V.	Signal ground must be connected to the controller.	25	N.C.	(Note 2)

- The motor temperature sensor input is supported on 7225X1. J2-21 must be grounded for amplifier to operate (motor temp sensor should be a normally-closed switch that opens when motor is too hot)

TYPICAL AMPLIFIER CONNECTIONS



PC BOARD LAYOUT



HEADER SOCKET COMPONENTS

Part	Value	Remarks
H15	N/a	No function
H14	86.6kΩ	I ² T Current Limit select
H13	0Ω<short>	I ² T Threshold Current select
H12	<out>	Ch. V Current Error Amp hi-frequency roll off
H11	30.1kΩ	Ch. V Current Error Amp proportional gain
H10	100nF	Ch. V Current Error Amp integrator
H9	<out>	Ch. U Current Error Amp hi-frequency roll off
H8	30.1kΩ	Ch. U Current Error Amp proportional gain
H7	100nF	Ch. V Current Error Amp integrator
H6	<out>	Ch. V Continuous Current Limit
H5	75kΩ	Ch. V Transconductance
H4	<out>	Ch. U Continuous Current Limit
H3	75kΩ	Ch. U Transconductance
H2	1.5MΩ	Ch. U Balance Range select
H1	1.5MΩ	Ch. V Balance Range select

HEADER SOCKET COMPONENT SELECTION

LOAD INDUCTANCE

L (mH)	H8, H11 @ 80V	H8, H11 @ 160V	H7, H10
0.4	16.5k	11k	33nF
1	32.4k	18.2k	33nF
3	86.6k	42.4k	33nF
10	249k	124k	33nF
30	750k	392k	33nF

Note: Table values apply with components H9 & H12 not installed. Values in **bold and italic** are factory installed.

CURRENT LIMITS

A micro controller uses an I²T algorithm to monitor to protect against overload conditions. The I²T overload protection for each channel operates independent of the other. The algorithm detects when the current in any phase exceeds the continuous current limit level set by the header component H13. The I²T algorithm tracks the energy of the overload (A² sec) and when the I²T limit is reached, the output current is limited to a level set by H4 and H6. The following tables or equations can be used to select header component values to obtain the desired over-current protection setting.

Cont. Current (A)	H4 & H6 (Ohm)	H13 (Ohm)
10	<out>	0 Ohms (short)
8	2.5k	16k
6	825	49k
4	383	150k
2	150	<out>

I ² T Limit (A ² sec)	H14 (Ohm)
1250	0 (short)
800	16k
450	49k
200	150k
50	<out>

$$H13 = 47.5k \text{ ohms} * \frac{(10 - I_{cont})}{(I_{cont} - 2)}$$

$$H14 = 47.5k \text{ ohms} * \frac{(6.25 - \sqrt{\frac{I^2 T_{limit}}{32}})}{(\sqrt{\frac{I^2 T_{limit}}{32}} - 1.25)}$$

Example: The I²T set point applies only to the energy delivered to the load over and above the continuous rating of the load. The amplifier's microchip is informed of the continuous current rating of the load via header resistor H13. The I²T set point is set via header resistor H14. Using a 0 Ohm value for H14 gives an I²T set point of 1250 A²*S. If a 0 ohm value is also used for H13, the continuous current setting is set to 10A. This means for a 25 Arms current on either phase U,V, or W, the I²T protection will activate (current is forced to continuous limit as set by H4,H6 after a time T = 1250 A²*S/(25²-10²) = 2.4 seconds.


BALANCE RANGE AND TRANSCONDUCTANCE SETTINGS

Header components H1 & H2 control the offset range. Default value is 1.5Mohm that gives a range of +/-350mA. The ratio between output current, and the reference voltage at the input is the *transconductance* of the amplifier. It is measured in Amps/Volt, and is controlled by components H3 & H5. The chart below gives some common settings.

Gain (A/V)	H3 & H5
2.5	102k
2.0	75.0k
1.5	59k
1	29.4k
0.5	14.3k

DIMENSIONS

Note: Dimensions in inches (mm.)



NOTES