

**Servo Control Modes**

- Profile Position-Velocity, Interpolated Position, Homing
- Indexer, Point-to-Point, PVT
- Camming, Gearing
- Position/Velocity/Torque

**Stepper Control Modes**

- Position (Microstepping)
- Position/Velocity/Torque (Servo Mode)
- Indexer, Point-to-Point, PVT
- Camming, Gearing

**Command Interface**

- CANopen
- ASCII and discrete I/O
- Stepper commands
- Master encoder (Gearing/Camming)

**Communications**

- CANopen
- RS-232

**Feedback**

- Digital quad A/B/X encoder

**I/O Digital**

- 24 HS inputs
- 8 MOSFET outputs


**I/O SPI**

- 1 HS input
- 4 HS outputs

**Dimensions: mm [in]**

- 101.6 x 76.2 x 20.83 [4.00 x 3.00 x 0.83]

**4-AXIS DIGITAL DRIVE FOR SERVO AND STEPPER MOTORS**



| Model      | Ic | Ip | Vdc   |
|------------|----|----|-------|
| MP4-055-03 | 3  | 3  | 14~55 |

**DESCRIPTION**

The MP4 is a four-axis, high-performance, DC powered drive for control of stepper or servo motors via CANopen. Each axis is configurable to drive a stepper, brushless, or brush motor. Using advanced FPGA technology, the MP4 provides a significant reduction in the cost per node by combining stepper and servo motors into a compact package.

Each axis in the MP4 operates as a CANopen node under CiA-402 for motion control devices. Supported modes include: Cyclic position/velocity/torque, Profile Position-Velocity, Interpolated Position Mode (PVT), and Homing.

Servo mode allows position/velocity/torque control. Servo mode allows CANopen or digital PWM control of position/velocity/torque. In microstepping mode stepper command pulses and master encoder for camming or gearing is supported.

Twenty-four high-speed digital inputs with programmable functions are provided. There are eight MOSFET outputs that are 24V compatible.

An SPI port is provided with one high-speed input and four high-speed digital outputs. If not used for SPI, the input and outputs are programmable for other functions.

An RS-232 serial port provides a connection to Copley's CME2 software for commissioning, firmware upgrading, and saving configurations to flash memory. The CANopen port is optically isolated.

Drive power is transformer-isolated DC from regulated or unregulated power supplies. An AuxHV input is provided for "keep-alive" operation permitting the drive power stage to be completely powered down without losing position information, or communications with the control system.

## GENERAL SPECIFICATIONS

Test conditions: Load = Bipolar stepper: 2 mH + 2 Ω per phase. Ambient temperature = 25°C, +HV = HV<sub>max</sub>

|   |   |                                    |
|---|---|------------------------------------|
| <b>MODEL</b>  | MP4-055-03  |                                    |
| <b>OUTPUT POWER (each axis)</b>   |   |                                    |
| Peak Current  | 3 (2.12)  | Adc (Arms-sine), ±5%               |
| Peak time   | 1   | Sec                                |
| Continuous current  | 3 (2.12)  | Adc (Arms-sine) per phase (Note 1) |
| Maximum Output Voltage  | Vout = HV*0.97 - Rout*Iout  |                                    |
| <b>INPUT POWER (module)</b>   |   |                                    |
| HVmin~HVmax   | +14 to +55  | Vdc Transformer-isolated           |
| Ipeak   | 3   | Adc (1 sec) peak                   |
| Icont   | 3   | Adc continuous (Note 1)            |
| Aux HV  | +14 to +55 Vdc, 6 W max with all four encoders powered, 3 W max with no encoders  |                                    |
| <b>PWM OUTPUTS</b>  |   |                                    |
| Type  | Dual H-bridge MOSFET, 12.5 kHz center-weighted PWM, space-vector modulation   |                                    |
| PWM ripple frequency  | 25 kHz  |                                    |
| <b>CONTROL MODES</b>  |   |                                    |
| CANopen: Profile Position/Velocity, Interpolated position, Homing   |   |                                    |
| Digital Inputs: Open-loop microstepping or servo position control with feedback, plus camming or internal indexer (CVM) |   |                                    |
| <b>COMMAND INPUTS</b>   |   |                                    |
| Type  | CANopen, galvanically isolated from drive circuits  |                                    |
| Signals & format  | TX+, TX-, RX+, RX-; 100BaseTX   |                                    |
| Data protocol   | CAN application layer over CANopen (CoE)  |                                    |
| Node-ID Selection   | Programmable, or via digital inputs. the A-Axis has a programmable unique, non-zero node-ID. The B, C, and D axes have ID that equal the A-Axis +1, +2, and +3  |                                    |
| Digital   | PWM/Polarity (Pls/Dir), Step/Direction (CW/CCW), 2 MHz max<br>Quad A/B encoder, 2 MLine/sec (8Mcount/sec after quadrature)  |                                    |
| Indexing  | Up to 32 sequences can be launched from digital inputs or ASCII commands  |                                    |
| Camming   | Quad A/B digital encoder, up to 10 Cam tables can be stored in flash memory   |                                    |
| ASCII   | RS-232 (see RS-232 Port, page 2)  |                                    |
| <b>DIGITAL CONTROL</b>  |   |                                    |
| Digital Control Loops   | Current, velocity, position. 100% digital loop control  |                                    |
| Sampling rate (time)  | Current loop: 12.5 kHz (80 μs), Velocity & position loops: 2.5 kHz (400 μs)   |                                    |
| Commutation   | Sinusoidal, field-oriented control for stepper and servo motors   |                                    |
| Modulation  | Center-weighted PWM with space-vector modulation  |                                    |
| Bandwidths  | Current loop: 2.5 kHz typical, bandwidth will vary with tuning & load inductance  |                                    |
| HV Compensation   | Changes in bus voltage do not affect bandwidth  |                                    |
| Minimum load inductance   | 200 μH line-line  |                                    |
| <b>DIGITAL INPUTS</b>   |   |                                    |
| [IN1~36]  | High-speed digital, 100 ns RC filter, 10 kΩ pull-up to +3.3 Vdc, +5V compatible<br>74LVC14 Schmitt trigger, Vcc = 3.3 Vdc, V <sub>T+</sub> = 1.2~2.0 Vdc, V <sub>T-</sub> = 0.8~1.5 Vdc, V <sub>H</sub> = 0.3~1.2 Vdc<br>Internal clamping diode to +5V at input of 74LVC14 |                                    |
| [IN1~24]  | General purpose inputs for digital commands, limit switches, etc.<br>Axis A feedback (A/B/X)<br>Axis B feedback (A/B/X)<br>Axis C feedback (A/B/X)<br>Axis D feedback (A/B/X)   |                                    |
| [IN25~27]   |   |                                    |
| [IN28~30]   |   |                                    |
| [IN31~33]   |   |                                    |
| [IN34~36]   |   |                                    |
| [IN37]  | SPI port MISO input, 47 ns RC filter, 1 kΩ pull-up to +3.3 Vdc, +5V compatible<br>74LVC2G14, Vcc = 3.3 Vdc, V <sub>T+</sub> = 1.56~2.64 Vdc, V <sub>T-</sub> = 0.72~1.80 Vdc, V <sub>H</sub> = 0.48~1.44 Vdc<br>Internal clamping diode to +5V at input of 74LV2G14         |                                    |
| All inputs are programmable for other functions than the ones shown above.  |   |                                    |
| <b>DIGITAL OUTPUTS</b>  |   |                                    |
| [OUT1~8]  | Open-drain MOSFET with 1 kΩ pull-up with series diode to +5 Vdc<br>300 mAdc max, +30 Vdc max. Functions programmable  |                                    |
| [OUT9~12]   | SPI port MOSI, SCLK, SS1, & SS2 signals, 74AHCT125 line drivers, +5V levels<br>Iout: -0.8 mA source at VOH= 2.4V, 6 mA sink at VOL= 0.5V  |                                    |
| <b>DC POWER OUTPUT</b>  |   |                                    |
| [ENC5V]   | +5 Vdc, 500 mA max, thermal and short-circuit protected   |                                    |
| <b>FEEDBACK</b>   |   |                                    |
| Digital Incremental Encoder   | Four groups of high-speed digital inputs programmed as A/B/X encoder inputs<br>Single-ended, +5V compatible<br>2 Mline/sec (8 Mcounts/sec) max when driven by active-output devices   |                                    |

### Notes:

1) Forced-air cooling may be required for operation at full output power on all axes.

**MOTOR CONNECTIONS (PER AXIS)**

|                             |   |
|-----------------------------|---|
| Stepper                     | Phases A, /A, B, /B, PWM outputs to 2-phase, 4-wire bipolar stepper motors                                    |
| Servo                       | Phases A, /A, /B for U, V, W brushless servo motors, or A, /A for brush servo motors                          |
| Digital Incremental Encoder | Quadrature signals, (A, B, X), using inputs [IN25~36]   |
| Encoder power               | 2 MHz maximum line frequency (8 M counts/sec) when driven by active devices<br>(See DC POWER OUTPUTS section) |

**RS-232 PORT**

|          |   |
|----------|---|
| Signals  | RxD, TxD, Gnd for operation as a DTE device                                     |
| Mode     | Full-duplex, DTE serial port for drive setup and control, 9,600 to 115,200 Baud |
| Protocol | ASCII or Binary format  |

**PROTECTIONS**

|                                   |  |  |
|-----------------------------------|--|--|
| HV Overvoltage                    | +HV > 55 Vdc   | Drive outputs turn off until +HV < 55 Vdc  |
| HV Undervoltage                   | +HV < +14 Vdc  | Drive outputs turn off until +HV > +14 Vdc |
| Drive over temperature            | Heat plate > 90°C.   | Drive outputs turn off                     |
| Short circuits                    | Output to output, output to ground, internal PWM bridge faults |  |
| I <sup>2</sup> T Current limiting | Programmable: continuous current, peak current, peak time      |  |

**MECHANICAL & ENVIRONMENTAL**

|                     |  |
|---------------------|--|
| Size mm [in]        | 101.6 x 76.2 x 20.83 [4.00 x 3.00 x 0.83]                      |
| Weight              | MP4: 0.09 kg [ 0.20 lb], MP4 + DevKit: 0.38 kg [0.84 lb]       |
| Ambient temperature | 0 to +45°C operating, -40 to +85°C storage                     |
| Humidity            | 0 to 95%, non-condensing                                       |
| Vibration           | 2 g peak, 10~500 Hz (sine), IEC60068-2-6                       |
| Shock               | 10 g, 10 ms, half-sine pulse, IEC60068-2-27                    |
| Contaminants        | Pollution degree 2   |
| Environment         | IEC68-2: 1990  |
| Cooling             | Forced air cooling may be required for continuous power output |

**AGENCY STANDARDS CONFORMANCE**

*In accordance with EC Directive 2014/30/EU (EMC Directive)*

|                        |   |
|------------------------|---|
| EN 55011: 2009/A1:2010 | CISPR 11:2009/A1:2010<br>Industrial, Scientific, and Medical (ISM) Radio Frequency Equipment –<br>Electromagnetic Disturbance Characteristics – Limits and Methods of Measurement<br>Group 1, Class A |
|------------------------|---|

|                    |   |
|--------------------|---|
| EN 61000-6-1: 2007 | Electromagnetic Compatibility (EMC) – Part 6-1: Generic Standards –<br>Immunity for residential, Commercial and Light-industrial Environments |
|--------------------|---|

*In accordance with EC Directive 2014/35/EU (Low Voltage Directive)*

|                  |  |
|------------------|--|
| IEC 61010-1:2010 | Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use |
|------------------|--|

*Underwriters Laboratory Standards*

|                              |   |
|------------------------------|---|
| UL 61010-1, 3rd Ed.: 2012-05 | Electrical Equipment for Measurement, Control and Laboratory Use;<br>Part 1: General Requirements |
|------------------------------|---|

*UL File Number E168959*

**CONTROL MODES AND COMMAND INPUTS**

This chart shows the possible combinations of Control Modes and the Command Inputs that are available in each mode. Servo mode is the use of encoder feedback to operate the stepper as a brushless motor.

| Command Source                | Control Mode |          |        | Motor Mode |       |
|-------------------------------|--------------|----------|--------|------------|-------|
|                               | Position     | Velocity | Torque | Microstep  | Servo |
| CANopen Profile Position      | √            |          |        | √          | √     |
| CANopen Profile Velocity      |              | √        |        | √          | √     |
| CANopen Homing                | √            |          |        | √          | √     |
| CANopen Interpolated Position | √            |          |        | √          | √     |
| Quad A/B Encoder              | √            |          |        |            |       |
| Digital Pls/Dir               | √            |          |        |            |       |
| Digital CW/CCW                | √            |          |        |            |       |
| Digital PWM                   |              | √        | √      |            | √     |
| CVM Indexer Position          | √            |          |        | √          | √     |
| CVM Indexer Velocity          |              | √        |        | √          | √     |

Notes:

- 1) Microstep = stepper motor with no feedback, Servo = stepper motor with feedback in servo mode, or brushless/brush servo motor with feedback.

**CME 2 SOFTWARE**


Drive setup is fast and easy using *CME 2* software. All of the operations needed to configure the drive are accessible through this powerful and intuitive program. Auto-phasing of brushless motor Hall sensors and phase wires eliminates "wire and try". Connections are made once and *CME 2* does the rest thereafter. Encoder wire swapping to establish the direction of positive motion is eliminated. Motor data can be saved as .CCM files. Drive data is saved as .CCX files that contain all drive settings plus motor data. This eases system management as files can be cross-referenced to drives. Once a drive configuration has been completed systems can be replicated easily with the same setup and performance.

**RS-232 COMMUNICATIONS**

*MP4* is configured via a three-wire, full-duplex DTE RS-232 port that operates from 9600 to 115,200 Baud, 8 bits, no parity, and one stop bit. Signal format is full-duplex, 3-wire, DTE using RxD, TxD, and Gnd. Connections to the *MP4* RS-232 port are through P2 The graphic below shows the connections between an *MP4* and a computer COM port which is a DTE device.

CME2 -> Tools -> Communications Wizard

RS232 PORT




DIGITAL COMMAND INPUTS


Digital commands are single-ended format and should be sourced from devices with active pull-up and pull-down to take advantage of the high-speed inputs. The active edge (rising or falling) is programmable for the Pulse/Dir and CU/CD formats.

DIGITAL POSITION


PULSE & DIRECTION



CU/CD (PULSE UP / PULSE DOWN)




QUAD A/B ENCODER




HOW IT LOOKS IN CME2

CME2 -> Basic Setup -> Operating Mode Options



HOW IT LOOKS IN CME2

CME2 -> Basic Setup -> Operating Mode Options



This screen shows the configuration screen for Pulse & Direction. CU/CD and Quad A/B encoder are selectable on this screen, too.

SIGNALS & PINS

The pins in the chart are on connector P3. The functions shown are the defaults. These can be programmed for other functions.

| Functions |       |     | Axis A |        | Axis B |        | Axis C |        | Axis D |        |
|-----------|-------|-----|--------|--------|--------|--------|--------|--------|--------|--------|
|           |       |     | Pins   | Signal | Pins   | Signal | Pins   | Signal | Pins   | Signal |
| Enc A     | Pulse | CW  | 19     | [IN5]  | 25     | [IN11] | 31     | [IN17] | 37     | [IN23] |
| Enc B     | Dir   | CCW | 20     | [IN6]  | 26     | [IN12] | 32     | [IN18] | 38     | [IN24] |


Note:

- The functions shown for [IN5~6], [IN11~12], [IN17~18] and [IN23~24] apply when they are used as digital command inputs for position control. These inputs are programmable if not used for these functions.


DIGITAL COMMAND INPUTS (CONT'D)

DIGITAL TORQUE, VELOCITY

PWM COMMAND (100% DUTY CYCLE)




PWM COMMAND (50% DUTY CYCLE)




HOW IT LOOKS IN CME2

CME2 -> Basic Setup -> Operating Mode Options



CME2 -> Main Page-> PWM Command



This screen shows the 50% Duty Cycle selection. Other modes are selectable via radio buttons and pull-down menus for Operating Mode and Command Source.

SIGNALS & PINS

The pins in the chart are on connector P3

| Function |         | Axis A |        | Axis B |        | Axis C |        | Axis D |        |
|----------|---------|--------|--------|--------|--------|--------|--------|--------|--------|
|          |         | Pins   | Signal | Pins   | Signal | Pins   | Signal | Pins   | Signal |
| PWM      | PWM 50% | 19     | [IN5]  | 25     | [IN11] | 31     | [IN17] | 37     | [IN23] |
| Polarity | n/a     | 20     | [IN6]  | 26     | [IN12] | 32     | [IN18] | 38     | [IN24] |


Note:

- The functions shown for [IN5~6], [IN11~12], [IN17~18] and [IN23~24] apply when they are used as digital command inputs for position control. These inputs are programmable if not used for these functions.

DIGITAL COMMAND INPUTS

HIGH SPEED INPUTS [IN1~24]

5V tolerant



HI/LO DEFINITIONS: INPUTS

| Input  | State | Condition      |
|--------|-------|----------------|
| IN1~25 | HI    | Vin >= 2.2 Vdc |
|        | LO    | Vin <= 0.8 Vdc |

Note: Inputs [IN1~24] are have default functions for commands and switches. Inputs [IN25~36] have default functions as encoder feedback inputs. All inputs are programmable for other functions.

INPUT/OUTPUT


DIGITAL INPUTS

MP4 has 24 high-speed digital inputs, all of which have programmable functions. They are compatible with 5V logic and have 100 ns R/C filters when driven by devices with active pull-up/pull-down outputs.

Programmable functions of the digital inputs include:

- Drive Enable
- Positive Limit switch
- Negative Limit switch
- Digital Command Inputs
- Home switch
- Drive Reset
- Motion abort

HIGH-SPEED DIGITAL INPUTS  
+5 VDC MAX



SIGNALS & PINS

The pins in the chart are on connector P3. The functions shown are the defaults. These can be programmed for other functions.


| Functions |       |     |          |         | Axis A |        | Axis B |        | Axis C |        | Axis D |        |
|-----------|-------|-----|----------|---------|--------|--------|--------|--------|--------|--------|--------|--------|
|           |       |     |          |         | Pins   | Signal | Pins   | Signal | Pins   | Signal | Pins   | Signal |
| Enable    |       |     |          |         | 15     | [IN1]  | 21     | [IN7]  | 27     | [IN13] | 33     | [IN19] |
| Pos Limit |       |     |          |         | 16     | [IN2]  | 22     | [IN8]  | 28     | [IN14] | 34     | [IN20] |
| Neg Limit |       |     |          |         | 17     | [IN3]  | 23     | [IN9]  | 29     | [IN15] | 35     | [IN21] |
| Enc A     | Pulse | CW  | PWM      | PWM 50% | 19     | [IN5]  | 25     | [IN11] | 31     | [IN17] | 37     | [IN23] |
| Enc B     | Dir   | CCW | Polarity | n/a     | 20     | [IN6]  | 26     | [IN12] | 32     | [IN18] | 38     | [IN24] |

Note: Inputs [IN1~24] are have default functions for commands and switches. Inputs [IN25~36] have default functions as encoder feedback inputs. All inputs are programmable for other functions.


DIGITAL OUTPUTS

Digital outputs [OUT1~8] are open-drain MOSFETs with 1 kΩ pull-up resistors in series with a diode to +5 Vdc. They can sink up to 300 mAdc from external loads operating from power supplies to +30 Vdc. The outputs are typically configured as drive fault and motor brake. Additional functions are programmable. As a drive fault output, the active level is programmable to be HI or LO when a fault occurs. As a brake output, it is programmable to be either HI or LO to release a motor brake when the drive is enabled. When driving inductive loads such as a relay, an external fly-back diode is required. A diode in the output is for driving PLC inputs that are opto-isolated and connected to +24 Vdc. The diode prevents conduction from +24 Vdc through the 1 kΩ resistor to +5 Vdc in the drive. This could turn the PLC input on, giving a false indication of the drive output state.

DIGITAL OUTPUTS  
30 VDC, 300 MA MAX




DRIVING INDUCTIVE LOADS



## DIGITAL INPUT DETAILS

### HOW IT LOOKS IN CME2

CME2 -> Main Page-> Input/Output -> Digital Inputs 1-12



**Notes:**

The functions for all of the inputs are programmable. The functions shown above are defaults for the combinations listed below:


- [IN1] and [IN7] are the defaults for the Enable function.
- [IN2~4] and [IN8~10] are the Hall signal defaults when used on brushless servo motors.
- IN5~6] and [IN11~12] are the digital command input defaults for position, velocity, or torque control.

### DIGITAL INPUT PINS AND FUNCTIONS

| Functions |       |     |          |         | Axis A |        | Axis B |        |
|-----------|-------|-----|----------|---------|--------|--------|--------|--------|
|           |       |     |          |         | Pins   | Signal | Pins   | Signal |
| Enable    |       |     |          |         | 15     | [IN1]  | 21     | [IN7]  |
| Hall U    |       |     |          |         | 16     | [IN2]  | 22     | [IN8]  |
| Hall V    |       |     |          |         | 17     | [IN3]  | 23     | [IN9]  |
| Hall W    |       |     |          |         | 18     | [IN4]  | 24     | [IN10] |
| Enc A     | Pulse | CW  | PWM      | PWM 50% | 19     | [IN5]  | 25     | [IN11] |
| Enc B     | Dir   | CCW | Polarity | n/a     | 20     | [IN6]  | 26     | [IN12] |

### HIGH SPEED DIGITAL INPUTS [IN1~IN12]

5V tolerant



### HIGH SPEED DIGITAL INPUTS [IN1~IN12] 5V tolerant


| Input  | State | Condition      |
|--------|-------|----------------|
| IN1~12 | HI    | Vin >= 2.2 Vdc |
|        | LO    | Vin <= 0.8 Vdc |



DIGITAL INPUT DETAILS

HOW IT LOOKS IN CME2

CME2 -> Main Page-> Input/Output -> Digital Inputs 13-25



Notes:


The functions for all of the inputs are programmable. The functions shown above are defaults for the combinations listed below:

- [IN13] and [IN19] are the defaults for the Enable function.
- [IN14~16] and [IN21~22] are the Hall signal defaults when used on brushless servo motors.
- [IN17~18] and [IN23~24] are the digital command input defaults for position, velocity, or torque control.

DIGITAL INPUT PINS AND FUNCTIONS

| Functions |       |     |          |         | Axis C |        | Axis D |        |
|-----------|-------|-----|----------|---------|--------|--------|--------|--------|
|           |       |     |          |         | Pins   | Signal | Pins   | Signal |
| Enable    |       |     |          |         | 27     | [IN13] | 33     | [IN19] |
| Hall U    |       |     |          |         | 28     | [IN14] | 34     | [IN20] |
| Hall V    |       |     |          |         | 29     | [IN15] | 35     | [IN21] |
| Hall W    |       |     |          |         | 30     | [IN16] | 36     | [IN22] |
| Enc A     | Pulse | CW  | PWM      | PWM 50% | 31     | [IN17] | 37     | [IN23] |
| Enc B     | Dir   | CCW | Polarity | n/a     | 32     | [IN18] | 38     | [IN24] |

HIGH SPEED DIGITAL INPUTS [IN13~IN24]  
5V tolerant



HI/LO DEFINITIONS: INPUTS

| Input  | State | Condition      |
|--------|-------|----------------|
| IN1~12 | HI    | Vin >= 2.2 Vdc |
|        | LO    | Vin <= 0.8 Vdc |

IN25 SPI\_MISO


If the SPI port is not used, [IN25] is programmable for other functions.

| Input  | State | Condition      |
|--------|-------|----------------|
| IN25   | HI    | Vin >= 2.2 Vdc |
|        | LO    | Vin <= 0.8 Vdc |
| P2 Pin | 9     | [IN25]         |

DIGITAL OUTPUT DETAILS

HOW IT LOOKS IN CME2

CME2 -> Main Page-> Input/Output -> Digital Outputs 1-6




HI/LO DEFINITIONS: OUTPUTS 1~6

| Output | State | Condition  |
|--------|-------|------------|
| OUT1~6 | HI    | MOSFET OFF |
|        | LO    | MOSFET ON  |


DIGITAL OUTPUTS PINS AND STRUCTURE

| Function | Pin |
|----------|-----|
| [OUT1]   | 41  |
| [OUT2]   | 42  |
| [OUT3]   | 43  |
| [OUT4]   | 44  |
| [OUT5]   | 45  |
| [OUT6]   | 46  |

MOSFET DIGITAL OUTPUTS




MOSFET DIGITAL OUTPUTS: INDUCTIVE LOADS



DIGITAL OUTPUT DETAILS

HOW IT LOOKS IN CME2

CME2 -> Main Page-> Input/Output -> Digital Outputs 7-12



HI/LO DEFINITIONS: OUTPUTS

| Output  | State | Condition       |
|---------|-------|-----------------|
| OUT7~8  | HI    | MOSFET OFF      |
|         | LO    | MOSFET ON       |
| OUT9~12 | HI    | Vout >= 2.2 Vdc |
|         | LO    | Vout <= 0.8 Vdc |


MOSFET OUTPUTS & PINS

| Output | P5 Pin |
|--------|--------|
| [OUT7] | 47     |
| [OUT8] | 48     |


SPI OUTPUTS & PINS

| Output  | P5 Pin |
|---------|--------|
| [OUT9]  | 31     |
| [OUT10] | 32     |
| [OUT11] | 33     |
| [OUT12] | 34     |

MOSFET DIGITAL OUTPUTS [OUT7~8] WITH INDUCTIVE LOAD  
300 mA max, 30Vdc max




HIGH SPEED DIGITAL (SPI) OUTPUTS [OUT9~12]  
74HCT125  
5V max



SPI PORT

This graphic shows all of the SPI port outputs and input together. The connections shown are those used on the MP4 Development Kit as an example of the port's usage for inputs and outputs.



HI/LO DEFINITIONS: OUTPUTS

| Input     | State | Condition       |
|-----------|-------|-----------------|
| [OUT9~12] | HI    | Vout >= 2.2 Vdc |
|           | LO    | Vout <= 0.8 Vdc |

SIGNALS & PINS


| Output  | P2 Pin |
|---------|--------|
| [OUT9]  | 10     |
| [OUT10] | 8      |
| [OUT11] | 6      |
| [OUT12] | 4      |
| [IN25]  | 9      |
| Sgnd    | 2      |

MOTOR CONNECTIONS


Motor connections consist of: phases, encoder, and brake. The phase connections carry the drive output currents that drive the motor to produce motion. The encoder signals give position feedback and are used for velocity and position modes. A brake can provide a fail-safe way to prevent movement of the motor when the drive is shut-down or disabled.

SINGLE-ENDED ENCODER CONNECTIONS

Single-ended (SE) encoders must have active outputs (not open-collector). Cables should be shielded because SE encoders are more susceptible to electrical interference than differential-output encoders. And, they not be routed together with the phase connections which have PWM waveforms that could couple noise into encoder cabling.



CME2 -> Motor/Feedback -> Feedback




Important:

The MP4 +5V output is rated at 500 mA max which must be shared between encoders that are connected to it. If the combined current of four encoders is greater than 500 mA, then the mounting board of the MP4 must have +5V to power the devices. If external +5V power is used for encoders, DO NOT CONNECT THIS TO THE +5V OUTPUT OF THE MP4. Encoders and/or other circuits may be powered either from external or MP4 +5V outputs as long as they both connect to Signal Ground.

DIFFERENTIAL ENCODER CONNECTIONS

To convert differential encoder outputs to single-ended signals, a line receiver must be mounted to the users PC board. Terminating resistors are also recommended to ensure signal quality. The maximum +5V output current from the MP4 is 500 mA which must support a maximum of four encoders. When using line receivers for differential encoders, the user must consider the total +5V power required for the four encoders and line receivers. If this exceeds 500 mA (2.5W) then the line receivers and/or encoders should be powered from a +5V source on the mounting PC board.



This graphic shows both encoder and line-receiver powered from the MP4 +5V output. If four encoders are connected like this, and assuming 25 mA for each line-receiver, then the available +5V power for each encoder would be 100 mA. If the encoder power requirement is greater than 100 mA, then external +5V on the mounting board must be used in addition to the +5V from the MP4. If external +5V power is used for encoders, DO NOT CONNECT THIS TO THE +5V OUTPUT OF THE MP4.

SIGNALS & PINS


The pins in the chart are on connector P3

| Functions | Axis A | Axis B | Axis C | Axis D |
|-----------|--------|--------|--------|--------|
|           | Pins   | Pins   | Pins   | Pins   |
| Enc A     | 1      | 2      | 7      | 8      |
| Enc B     | 3      | 4      | 9      | 10     |
| Enc X     | 5      | 6      | 11     | 12     |

## MOTOR CONNECTIONS


### STEPPER MOTORS

The drive outputs are two H-bridge PWM inverters that convert the DC bus voltage (+HV) into sinusoidal voltage waveforms that drive the motor phase-coils. Cable should be sized for the continuous current rating of the drive. Motor cabling should use twisted, shielded conductors for CE compliance, and to minimize PWM noise coupling into other circuits. The motor cable shield should connect to motor frame and the drive HV ground terminal for best results.



### HOW IT LOOKS IN CME2

CME2 -> Basic Setup -> Motor Options




### SIGNALS & PINS

The pins in the chart are on connector P3

| Output | Motor   | Axis A | Axis B | Axis C | Axis D |
|--------|---------|--------|--------|--------|--------|
|        |         | Pins   | Pins   | Pins   | Pins   |
| Mot A  | A       | 18     | 26     | 34     | 42     |
| Mot /A | /A      | 17     | 25     | 33     | 41     |
| Mot B  | B       | 16     | 24     | 32     | 40     |
| Mot /B | /B      | 15     | 23     | 31     | 39     |
| +HV    | 1,2,3,4 |        |        |        |        |
| 0V     | 5,6,7,8 |        |        |        |        |
| +AuxHV | 9       |        |        |        |        |


### BRUSH MOTORS

The drive outputs are an H-bridge PWM inverter that convert the DC bus voltage (+HV) into DC voltage waveforms that drive the motor (+) & (-) terminals. Cable should be sized for the continuous current rating of the drive. Motor cabling should use twisted, shielded conductors for CE compliance, and to minimize PWM noise coupling into other circuits. The motor cable shield should connect to motor frame and the drive HV ground terminal for best results.



### HOW IT LOOKS IN CME2

CME2 -> Basic Setup -> Motor Options



### SIGNALS & PINS


The pins in the chart are on connector P3

| Output | Motor   | Axis A | Axis B | Axis C | Axis D |
|--------|---------|--------|--------|--------|--------|
|        |         | Pins   | Pins   | Pins   | Pins   |
| Mot A  |         | n/c    |        |        |        |
| Mot /A | (+)     | 17     | 25     | 33     | 41     |
| Mot /B | (-)     | 15     | 23     | 31     | 39     |
| +HV    | 1,2,3,4 |        |        |        |        |
| 0V     | 5,6,7,8 |        |        |        |        |
| +AuxHV | 9       |        |        |        |        |

MOTOR CONNECTIONS


BRUSHLESS MOTORS

The drive outputs are a 3-phase PWM inverter that converts the DC bus voltage (+HV) into sinusoidal voltage waveforms that drive the motor U-V-W terminals. Cable should be sized for the continuous current rating of the drive. Motor cabling should use twisted, shielded conductors for CE compliance, and to minimize PWM noise coupling into other circuits. The motor cable shield should connect to motor frame and the drive HV ground terminal for best results.



HOW IT LOOKS IN CME2

CME2 -> Basic Setup -> Motor Options



SIGNALS & PINS

The pins in the chart are on connector P3


| Output | Motor         | Axis A  | Axis B  | Axis C  | Axis D  |
|--------|---------------|---------|---------|---------|---------|
|        |               | J2 Pins | J2 Pins | J2 Pins | J2 Pins |
| Mot A  | W             | 18      | 26      | 34      | 42      |
| Mot /A | U             | 17      | 25      | 33      | 41      |
| Mot B  | No Connection |         |         |         |         |
| Mot /B | V             | 15      | 23      | 31      | 39      |
| +HV    | 1,2,3,4       |         |         |         |         |
| 0V     | 5,6,7,8       |         |         |         |         |
| +AuxHV | 9             |         |         |         |         |

DIGITAL HALL SIGNALS

Hall signals are single-ended signals that provide absolute feedback within one electrical cycle of the motor. There are three of them (U, V, & W) and they may be sourced by magnetic sensors in the motor, or by encoders that have Hall tracks as part of the encoder disc. They typically operate at much lower frequencies than the motor encoder signals, and are used for commutation-initialization after startup, and for checking the motor phasing after the servo drive has switched to sinusoidal commutation.

HOW IT LOOKS IN CME2


CME2 -> Basic Setup -> Feedback Options



Note: Hall phase correction is optional

HALL INPUTS

5V



SIGNALS & PINS

The pins in the chart are on connector P3


| Functions | Axis A |        | Axis B |        | Axis C |        | Axis D |        |
|-----------|--------|--------|--------|--------|--------|--------|--------|--------|
|           | Pins   | Signal | Pins   | Signal | Pins   | Signal | Pins   | Signal |
| Hall U    | 16     | [IN2]  | 22     | [IN8]  | 28     | [IN14] | 34     | [IN20] |
| Hall V    | 17     | [IN3]  | 23     | [IN9]  | 29     | [IN15] | 35     | [IN21] |
| Hall W    | 18     | [IN4]  | 24     | [IN10] | 30     | [IN16] | 36     | [IN22] |

If these pins are not used for Hall signals, they can be programmed for other functions.

CANOPEN NODE-ID (ADDRESS)


CANOPEN AND NODE ID

The Node-ID of the MP4 can be set in flash memory, or read from 16-position switches via an SPI port. An SPI port circuit and switches is included in the MP4 Development Kit. Users can add this circuit to their own mounting boards. The Node ID can be set in flash memory using Copley CME2 software. On a CAN network, the MP4 will appear as four nodes. When the "base" Node-ID is configured either via SPI or flash programming, it will address Axis A. Axes B,C, and D will then be automatically assigned Node-ID's based on the base ID. The Axis-B ID will be Axis-A ID +1. Axis-C will be Axis-A +2, and Axis-D will be Axis-A ID+3. Whatever Node-ID is assigned to the MP4, a total of four IDs with consecutive values are required. In the graphic below, the base ID of the MP4 is set to 5 resulting in IDs of 5,6,7, and 8 for the four axes. Node-ID 0 is reserved for the CANopen Master, and the maximum Node-ID allowed is 127. This leaves ID 1~4, and 9~127 available for use by other devices on the network.



CANOPEN CONNECTIONS FOR MULTIPLE MODULES


The graphic below shows two MP4 wired to a CAN network. The lowest Node-ID allowable on a CAN network is 1 which will allocate IDs 1,2,3, and 4 for MP4 #1. MP4 #2 must have a minimum Node-ID equal to Node-ID#1+4 which equals 5 as shown.





TYPICAL CONNECTIONS

Here is an example using a stepper motor with encoder feedback, driving a linear stage with positive and negative limit switches, and a home switch. Position commands are shown as digital inputs. For CANopen operation, these would not be used.



Axis A is shown as an example. The tables below show the pins for the same-named signals for axes B, C, and D.

INPUT SIGNALS & PINS

| Functions             |       |     |          |         | Axis A |        | Axis B |        | Axis C |        | Axis D |        |
|-----------------------|-------|-----|----------|---------|--------|--------|--------|--------|--------|--------|--------|--------|
|                       |       |     |          |         | Pins   | Signal | Pins   | Signal | Pins   | Signal | Pins   | Signal |
| Enable                |       |     |          |         | 15     | [IN1]  | 21     | [IN7]  | 27     | [IN13] | 33     | [IN19] |
| Positive Limit Switch |       |     |          |         | 16     | [IN2]  | 22     | [IN8]  | 28     | [IN14] | 34     | [IN20] |
| Negative Limit Switch |       |     |          |         | 17     | [IN3]  | 23     | [IN9]  | 29     | [IN15] | 35     | [IN21] |
| Home Switch           |       |     |          |         | 18     | [IN4]  | 24     | [IN10] | 30     | [IN16] | 36     | [IN22] |
| Enc A                 | Pulse | CW  | PWM      | PWM 50% | 19     | [IN5]  | 25     | [IN11] | 31     | [IN17] | 37     | [IN23] |
| Enc B                 | Dir   | CCW | Polarity | n/a     | 20     | [IN6]  | 26     | [IN12] | 32     | [IN18] | 38     | [IN24] |

Notes:

- 1) Inputs functions shown for [IN1], [IN7], [IN13], and [IN19] are the default functions. These inputs are programmable if not used for these functions.
- 2) The functions shown for [IN5~6], [IN11~12], [IN17~18] and [IN23~24] apply when they are used as digital command inputs for position control. These inputs are programmable if not used for these functions.
- 3) The functions shown for [IN2~4] are typical inputs. These inputs are programmable if not used for these functions.

ENCODER SIGNALS & PINS

| Functions | Axis A | Axis B | Axis C | Axis D |
|-----------|--------|--------|--------|--------|
|           | Pins   | Pins   | Pins   | Pins   |
| Enc A     | 1      | 2      | 7      | 8      |
| Enc B     | 3      | 4      | 9      | 10     |
| Enc X     | 5      | 6      | 11     | 12     |


MOSFET OUTPUTS & PINS

| Output | P3 Pin | Output | P3 Pin |
|--------|--------|--------|--------|
| [OUT1] | 41     | [OUT5] | 45     |
| [OUT2] | 42     | [OUT6] | 46     |
| [OUT3] | 43     | [OUT7] | 47     |
| [OUT4] | 44     | [OUT8] | 48     |

The pins in these charts are on connector P3

MODULE DIMENSIONS

Units in inch (mm)





PRINTED CIRCUIT BOARD FOOTPRINT

Dimensions are inch (mm)

TOP VIEW

Viewed from above looking down on the connectors or PC board footprint to which the module is mounted

PC Board Pad Grouping for current-sharing See Note 1



Mounting Hardware:

| Qty | Description          | Mfgr   | Part Number    | Remarks              |
|-----|----------------------|--------|----------------|----------------------|
| 1   | Socket Strip         | Samtec | SQW-121-01-L-D | P1: HV, Aux, & Motor |
| 1   | Socket Strip         | Samtec | SQW-105-01-L-D | P2: SPI port         |
| 1   | Socket Strip         | Samtec | SQW-128-01-L-D | P3: Input/Output     |
| 2   | Standoff 6-32 X 1/4" | PEM    | KFE-632-8ET    |                      |

Notes

1. P1 signals of the same name must be connected for current-sharing (see graphic above).
2. To determine copper width and thickness for P1 signals refer to specification IPC-2221. (Association Connecting Electronic Industries, <http://www.ipc.org>)

MOUNTING PC BOARD CONNECTORS & SIGNALS

**P4 POWER**

Mounting board connector:  
Samtec SQW-121-01-L-D

| Axis           | Signal | Pin | Signal | Axis           |
|----------------|--------|-----|--------|----------------|
| D              | Mot /A | 41  | 42     | Mot A          |
|                | Mot /B | 39  | 40     | Mot B          |
| No connections |        | 37  | 38     | No connections |
|                |        | 35  | 36     |                |
| C              | Mot /A | 33  | 34     | Mot A          |
|                | Mot /B | 31  | 32     | Mot B          |
| No connections |        | 29  | 30     | No connections |
|                |        | 27  | 28     |                |
| B              | Mot /A | 25  | 26     | Mot A          |
|                | Mot /B | 23  | 24     | Mot B          |
| No connections |        | 21  | 22     | No connections |
|                |        | 19  | 20     |                |
| A              | Mot /A | 17  | 18     | Mot A          |
|                | Mot /B | 15  | 16     | Mot B          |
| No connections |        | 13  | 14     | No connections |
|                |        | 11  | 12     |                |
| HVaux          |        | 9   | 10     |                |
| HV Gnd         |        | 7   | 8      | HV Gnd         |
|                |        | 5   | 6      |                |
| +HV            |        | 3   | 4      | +HV            |
|                |        | 1   | 2      |                |

**P2 SPI PORT**


Mounting board connector:  
Samtec SQW-105-01-L-D

| Signal   | Pin | Signal |
|----------|-----|--------|
| SPI-MISO | 9   | 10     |
| Sgnd     | 7   | 8      |
| Sgnd     | 5   | 6      |
| +5V-ENC  | 3   | 4      |
| Sgnd     | 1   | 2      |

Signal names in this chart are default settings that configure the port for the SPI function. If the SPI function is not used, the input and outputs on P2 are programmable for other functions.

**TOP VIEW**

Viewed from above looking down on the connectors or PC board footprint to which the module is mounted




**CONNECTOR NAMING (P1, P2, ETC) APPLIES TO THE MP4 MODULE AND NOT TO PC BOARD MOUNTED SOCKETS**

**P3 INPUT/OUTPUT**

Mounting board connector:  
Samtec SQW-128-01-L-D

**TOP VIEW**

Viewed from above looking down on the connectors or PC board footprint to which the module is mounted



**CONNECTOR NAMING (P1, P2, ETC) APPLIES TO THE MP4 MODULE AND NOT TO PC BOARD MOUNTED SOCKETS**


| Signal               | Pin |    | Signal               |
|----------------------|-----|----|----------------------|
| ENC-A Axis-B         | 2   | 1  | Axis-A ENC-A         |
| ENC-B Axis-B         | 4   | 3  | Axis-A ENC-B         |
| ENC-X Axis-B         | 6   | 5  | Axis-A ENC-X         |
| ENC-A Axis-D         | 8   | 7  | Axis-C ENC-A         |
| ENC-B Axis-D         | 10  | 9  | Axis-C ENC-B         |
| ENC-X Axis-D         | 12  | 11 | Axis-C ENC-X         |
| ENC5V                | 14  | 13 | Signal Gnd           |
| Axis-A Hall-U [IN2]  | 16  | 15 | [IN1] Axis-A Enable  |
| Axis-A Hall-W [IN4]  | 18  | 17 | [IN3] Axis-A Hall-V  |
| Axis-A Dir [IN6]     | 20  | 19 | [IN5] Axis-A Pulse   |
| Axis-B Hall-U [IN8]  | 22  | 21 | [IN7] Axis-B Enable  |
| Axis-B Hall-W [IN10] | 24  | 23 | [IN9] Axis-B Hall-V  |
| Axis-B Dir [IN12]    | 26  | 25 | [IN11] Axis-B Pulse  |
| Axis-C Hall-U [IN14] | 28  | 27 | [IN13] Axis-C Enable |
| Axis-C Hall-W [IN16] | 30  | 29 | [IN15] Axis-C Hall-V |
| Dir Axis-C [IN18]    | 32  | 31 | [IN17] Axis-C Pulse  |
| Axis-D Hall-U [IN20] | 34  | 33 | [IN19] Axis-D Enable |
| Axis-D Hall-W [IN22] | 36  | 35 | [IN21] Axis-D Hall-V |
| Axis-D Dir [IN24]    | 38  | 37 | [IN23] Axis-D Pulse  |
| Signal Gnd           | 40  | 39 | Signal Gnd           |
| MOSFET [OUT2]        | 42  | 41 | [OUT1] MOSFET        |
| MOSFET [OUT4]        | 44  | 43 | [OUT3] MOSFET        |
| MOSFET [OUT6]        | 46  | 45 | [OUT5] MOSFET        |
| MOSFET [OUT8]        | 48  | 47 | [OUT7] MOSFET        |
| Signal Gnd           | 50  | 49 | Signal Gnd           |
| RS-232 RxD           | 52  | 51 | RS-232 TxD           |
| Signal Gnd           | 54  | 53 | CAN_GND              |
| CAN_L                | 56  | 55 | CAN_H                |

Signal names in this chart are default settings for brushless motors with Halls, position mode, and command source from digital inputs. Digital inputs [IN1~IN24] are programmable for other functions. Outputs [OUT1~OUT8] are programmable for other functions.

**DESCRIPTION**

The Development Kit provides mounting and connectivity for one MP4 drive. Solderless jumpers ease configuration of inputs and outputs to support their programmable functions. Switches can be jumpered to connect to digital inputs 1~20 so that these can be toggled to simulate equipment operation. LED's provide status indication for the digital outputs, encoder A/B/X/S signals, and Hall signals. Test points are provided for these signals, too, making it easy to monitor these with an oscilloscope.

Dual CANopen connectors make daisy-chain connections possible so that other CANopen devices such as Copley's Accelnet Plus or Xenus Plus CANopen drives can easily be connected. Rotary switches are provided to set the CANopen slave Node-ID (address).




**RS-232 CONNECTION**

The RS-232 port is used to configure the drive for stand-alone applications, or for configuration before it is installed into an CANopen network. CME 2™ software communicates with the drive over this link and is then used for complete drive setup. The CANopen Node-ID that is set by the rotary switch can be monitored, and a Node-ID offset programmed as well.

The RS-232 connector, J8, is a modular RJ-11 type that uses a 6-position plug, four wires of which are used for RS-232. A connector kit is available (SER-CK) that includes the modular cable, and an adaptor to interface this cable with a 9-pin RS-232 port on a computer.


The LEDs on J4 are for the CANopen network status of Axis A & B, and are not associated with the RS-232 port function.

**J8 SIGNALS**



**SER-CK SERIAL CABLE KIT**

The SER-CK provides connectivity between a D-Sub 9 male connector and the RJ-11 connector J8 on the Development Kit. It includes an adapter that plugs into the COM1 (or other) port of a PC and uses common modular cable to connect to the XEL. The connections are shown in the diagram below.




Don't forget to order a Serial Cable Kit SER-CK when placing your order for an MP4 Development Kit!

CANOPEN CONNECTORS

Dual RJ-45 connectors that accept standard Ethernet cables are provided for CAN bus connectivity. Pins are wired-through so that drives can be daisy-chained and controlled with a single connection to the user's CAN interface. A CAN terminator should be placed in the last drive in the chain. The MPK-NK connector kit provides a D-Sub adapter that plugs into a CAN controller and has an RJ-45 socket that accepts the Ethernet cable.

MPK-NK CAN CONNECTOR KIT

The kit contains the MPK-CV adapter that converts the CAN interface D-Sub 9M connector to an RJ-45 Ethernet cable socket, plus a 10 ft (3 m) cable and terminator. Both connector pin-outs conform to the CiA DR-303-1 specification.



INDICATORS (LEDS)

The AMP LEDs DS17~20 at switches SW1, 7, 9, and 10 show the operational state of each axis of the MP4. The STATUS LEDs on J9 & J4 show the state of the CANopen NMT (Network Management) state-machines of each axis in the drive. Details on the NMT state-machine can be found in the CANopen Programmers Manual, §3.1: <http://www.copleycontrols.com/Motion/pdf/CANopenProgrammersManual.pdf>


AMP LEDES

Four bi-color LEDs show the states of each axis of the MP4 by changing color, and either blinking or remaining solid. The possible color and blink combinations are:

- *Green/Solid*: Drive OK and enabled. Will run in response to reference inputs or CANopen commands.
- *Green/Slow-Blinking*: Drive OK but NOT-enabled. Will change to *Green/Solid* when enabled.
- *Green/Fast-Blinking*: Positive or Negative limit switch active. Drive will only move in direction not inhibited by limit switch.
- *Red/Solid*: Transient fault condition. Drive will resume operation when fault is removed.
- *Red/Blinking*: Latching fault. Operation will not resume until drive is Reset.

Drive Fault conditions. Faults are programmable to be either transient or latching:

- Over or under-voltage
- Motor over-temperature
- Encoder +5 Vdc fault
- Short-circuits from output to ground
- Drive over-temperature
- Internal short circuits
- Short-circuits from output to output



STATUS LEDES

Four bi-color LEDs on J9 & J4 give the state of the NMT state-machine of each axis by changing color, and either blinking or remaining solid. The possible color and blink combinations are:


RUN (GREEN)

- Off
- Blinking
- Single-flash
- On
- Init
- Pre-operational
- Stopped
- Operational

ERROR (RED)

- Off
- Blinking
- Single Flash
- Double Flash
- Triple Flash
- On
- No error
- Invalid configuration, general configuration error
- Warning limit reached
- Error Control Event (guard or heartbeat event) has occurred
- Sync message not received within the configured period
- Bus Off, the CAN master is bus off

NETWORK STATUS LEDES



Note: Red & green led on-times do not overlap. LED color may be red, green, off, or flashing of either color.

CANopen Node ID (ADDRESS)


On a CANopen network, each device must have unique, non-zero Node-ID. In the MP4 DevKit, this is provided by two 16-position rotary switches with hexadecimal encoding. These can set the Node-ID of the drive's Axis A from 0x01~0xFF (1~255 decimal). The chart shows the decimal values of the hex settings of each switch.

Example 1: Find the switch settings for decimal Node-ID 107 (0x6B):


- 1) Find the highest number under SW2 that is less than 107 and set SW2 to the hex value in the same row: 96 < 107 and 112 > 107, so SW2 = 96 = Hex 6
- 2) Subtract 96 from the desired Node-ID to get the decimal value of switch SW3 and set SW3 to the Hex value in the same row: SW3 = (107 - 96) = 11 = Hex B
- 3) This example will produce the following CAN addresses for the MP4:  
Axis A = 107 (0x6B), Axis B = 108 (0x6C), Axis C = 109 (0x6D), Axis D = 110 (0x6E)

CME2 -> Amplifier -> Network Configuration

SW2 SW3




CME2 -> Input/Output -> Digital Outputs



CANopen Node-ID Switch Decimal values

| HEX | SW2 | SW3 |
|-----|-----|-----|
| 0   | 0   | 0   |
| 1   | 16  | 1   |
| 2   | 32  | 2   |
| 3   | 48  | 3   |
| 4   | 64  | 4   |
| 5   | 80  | 5   |
| 6   | 96  | 6   |
| 7   | 112 | 7   |
| 8   | 128 | 8   |
| 9   | 144 | 9   |
| A   | 160 | 10  |
| B   | 176 | 11  |
| C   | 192 | 12  |
| D   | 208 | 13  |
| E   | 224 | 14  |
| F   | 240 | 15  |



STATUS LEDs \*  
Note that the STATUS LED axis pin assignments to this IC are different than the ones for the AMP LEDs.

CANopen NODE-ID (ADDRESS) SWITCH CONNECTIONS

This graphic shows the connections to the CANopen Node-ID switches and to the status LEDs for the MP4 and CANopen. The switches are read once after the drive is reset, or powered-on. When changing the settings of the switches, be sure to either reset the drive, or to power it off-on. Outputs [OUT4,5,6] and input [IN18] operate as an SPI (Switch & LED Interface) port which reads the settings on the CANopen Node-ID switches, and controls the LEDs on the serial and CANopen port connectors.


The jumpers marked with red "X" should be removed so that SW18, or external connections to the signals do not interfere with the operation of the SPI port.



**+5V POWER**

The encoder +5VENC power on the feedback connectors J5~J8 is connected directly to the +5VENC power output from the MP4.

The SPI port components on the DevKit that drive the LEDs and read the Node-ID (address) switches connects to the signal +5VKIT. And the +5VKIT connects to a jumper on JP1 that selects source of the +5V power. This can be powered from either the +5VENC power from the MP4, or from an external +5V power supply that connects to P5-3. The default "A" position (on JP1 pins 1~2) selects the +5VENC from the MP4 as the power source for the +5VKIT. Moving the jumper to the "B" position (pins 3~4) selects the external +5V power source for +5VKIT. As noted below, only one jumper should be used to select the source of power for +5VKIT.



**IMPORTANT: ONLY ONE SHORTING PLUG CAN BE USED ON JP1-A or JP1-B POSITIONS  
USE OF MORE THAN ONE PLUG WILL DAMAGE 5V POWER SUPPLIES IN THE MP4**


**CAN BUS TERMINATOR: JP10**

The DevKit has a 121 ohm resistor that can be jumper-configured to be IN or OUT.

- IN = the resistor is a terminator between the CANH and CANL inputs.
- OUT = no terminator


When the MP4 is the only node on the CAN network, then the terminator should be IN.

When there are multiple MP4, or other devices on the CAN network, then only the last device (the farthest from the CAN master) should have a terminator.




MOSFET OUTPUTS

There are eight MOSFET outputs that can drive controller logic inputs or relays. If relays are driven, then flyback diodes must be connected across their terminals to clamp overvoltages that occur when the inductance of the relay coil is suddenly turned off. LED indicators connected to the outputs will be ON when the output is MOSFET is ON and the output voltage will be near 0V. Outputs 1,2, & 3 are MOSFET types that sink current when ON, and appear as open-circuit when OFF. When these outputs are ON a red LED is turned on. When the outputs are OFF, the red LED is off. The green LED is not used on these outputs.



LOGIC OUTPUTS

Outputs 9~12 are CMOS types that pull up to 5V or down to ground. When these outputs go high it turns on the green LED. When they are low, the red LED is turned on.




**LOGIC INPUTS & SWITCHES**

The Development Kit has jumpers that can connect the MP4 digital inputs to switches on the kit, or to the Signal connector J6.

As delivered, all of these jumpers are installed as shown. If connecting to external devices that actively control the level of an input, it is desirable to disconnect the switch which could short the input to ground.

For example, if [IN1] is connected to an external device for the Enable function, then jumper JP5A should be removed to take the switch SW1 out of the circuit. The figure below shows these connections.



DEVELOPMENT KIT CONNECTORS

The Development Kit mounts a single MP4 module and enables the user to test and operate the MP4 before it is mounted onto a PC board in the target system.

J5      J6      J7      J8  
 AXIS A    AXIS B    AXIS C    AXIS D FEEDBACK

| PIN | SIGNAL     | PIN | SIGNAL     | PIN | SIGNAL             |
|-----|------------|-----|------------|-----|--------------------|
| 26  | Signal Gnd | 18  | n.c.       | 9   | Enc X              |
| 25  | Signal Gnd | 17  | +5VENC     | 8   | n.c.               |
| 24  | n.c.       | 16  | Signal Gnd | 7   | n.c.               |
| 23  | n.c.       | 15  | n.c.       | 6   | +5VENC             |
| 22  | n.c.       | 14  | n.c.       | 5   | Signal Gnd         |
| 21  | n.c.       | 13  | Enc A      | 4   | Table 1<br>(below) |
| 20  | n.c.       | 12  | n.c.       | 3   |                    |
| 19  | n.c.       | 11  | Enc B      | 2   |                    |
|     |            | 10  | n.c.       | 1   | Frame Gnd          |

TABLE 1

This shows the signals connected to these pins on the axis feedback connectors J5~J8. The jumpers connect these pins to signals in the MP4.

| Pin | Axis A | Axis B | Axis C | Axis D |
|-----|--------|--------|--------|--------|
| 2   | IN2    | JP4-A  | IN8    | JP4-E  |
| 3   | IN3    | JP4-B  | IN9    | JP4-F  |
| 4   | IN4    | JP4-C  | IN10   | JP4-G  |
| 7   | IN5    | JP4-D  | IN11   | JP4-H  |

P4: AXIS D MOTOR  
 P3: AXIS C MOTOR  
 P2: AXIS B MOTOR  
 P1: AXIS A MOTOR


Connector, Euro, 4 Terminal, 5.08 mm

| Signal   | Pin |
|----------|-----|
| Motor A  | 1   |
| Motor /A | 2   |
| Motor B  | 3   |
| Motor /B | 4   |

P5: HV, AUX, GND

Connector, Euro, 5 Terminal, 5.08 mm

| Signal  | Pin |
|---------|-----|
| +HV     | 1   |
| HV Gnd  | 2   |
| +5V Ext | 3   |
| Sgnd    | 4   |
| HV Gnd  | 5   |
| HV Aux  | 6   |





MASTER ORDERING GUIDE

|            |  |
|------------|--|
| MP4-055-03 | MP4 Stepper and Servo drive, 3/3A, 14~55 Vdc |
| MPK-055-04 | Development Kit for MP4                      |



ACCESSORIES

|  | QTY | Ref   | Name      | DESCRIPTION   |
|--|-----|-------|-----------|---|
| Connector Kit for Development Kit<br>MPK-CK-04 | 1   | P5    | +HV & Aux | Connector, Euro, 6 Terminal, 5.08 mm                      |
|  | 4   | P1~P4 | Motor     | Connector, Euro, 4 Terminal, 5.08 mm                      |
|  | 1   | P6    | Control   | 44 Pin Connector, High Density, D-Sub, Female, Solder Cup |
|  |     |       |           | 44 Pin Connector Backshell                                |
|  | 4   | J5~J8 | Feedback  | 26 Pin Connector, High Density, D-Sub, Male, Solder Cup   |
|  | 4   |       |           | 26 Pin Connector Backshell                                |
| SER-CK   |     | J4    | RS-232    | Serial Cable Kit  |

CONNECTORS & ACCESSORIES FOR CANOPEN OPERATION

|                             | QTY | Ref |             | DESCRIPTION                         |
|-----------------------------|-----|-----|-------------|-------------------------------------|
| Network Cable Kit<br>MPK-NK | 1   | J9  | CAN Network | D-Sub 9F to RJ-45 Adapter           |
|                             | 1   |     |             | CAN bus RJ-45 terminator            |
|                             | 1   |     |             | CAN bus network cable, 10 ft (3 m)  |
| MPK-CV                      | 1   |     |             | D-Sub 9F to RJ-45 Adapter           |
| MPK-NC-10                   | 1   |     |             | CAN bus Network Cable, 10 ft (3 m)  |
| MPK-NC-01                   | 1   |     |             | CAN bus Network Cable, 1 ft (0.3 m) |
| MPK-NT                      | 1   |     |             | CAN bus Network Terminator          |

16-01546 Document Revision History

| Revision | Date          | Remarks                  |
|----------|---------------|--------------------------|
| 00       | July 28, 2016 | Initial released version |
| 01       | April 5, 2017 | ECO-066021               |
|          |               |                          |
|          |               |                          |

Note: Specifications subject to change without notice